

Soap Dish
6804-30-80SS

NO	Part NO.	Part Name	QTY
1	0804-A2-68SS	Base	1
2	0815-W2-4000	Tumbler	1
3	0861-71-68SS	Screw	1
4	0880-2A-54S1	Ring Holder	1
5	0880-B2-22SS	Support	1
6	0880-C0-22CR	Fixing Bracket	1
7	F026-00-7500	Plastic Anchor	2
8	F026-04-5400	Screw	2
9	F026-F0-66BN	Hex Key	1
10	F026-01-5400	Set Screw	1
11	F026-06-5400	Bolt	1

