

Soap Dish
6817-20-80CP

NO	Part NO.	Part Name	QTY
1	0815-X2-4000	Soap Dish	1
2	0807-Z0-68RB	Fixing Bracket	1
3	0811-CD-5400	Screw	1
4	F026-14-7500	Plastic Anchor	1
5	F026-F0-66BN	Hex Key	1
6	0807-2C-68CP	Holder	1
7	0817-3A-68CP	Support	1
8	F026-01-5400	Set Screw	1

